

Frozen Drink Machine Operating Instructions

1. Plug the machine in and make sure ALL switches are in the OFF POSITION. The switches are on the side of the machine. The machine must be plugged into a 20 amp, 110 volt dedicated circuit. The slush mix will not freeze properly if the machine does not have the correct power.
2. **Do not start the machine without mix in it!!!**
3. Keep ALL ingredients cold. The colder the mix, the faster it will freeze. We suggest storing alcohol in the freezer and slush mix in the refrigerator prior to mixing.
4. Prepare your mix by following the mixing ratio directions located on the front of the drink mix container. For easy mixing use the 5 gallon mixing jugs which comes with your machine. Pour the mix from the mixing jug into one or both sides of the machine up to the "FULL" line.
5. Once the machine is filled with the mix, turn ON the machine by pressing the power button, indicated by a Lightning Bolt on the control panel. None of the parts of the machine should be in motion at this time.
7. Once the main power button is turned on, switch the power button for each of the augers on as well. This will start the churning motion inside the machine. Place the lids on the machine at this time.
8. For frozen drinks switch on the temperature control button(s) to the Snowflake position. To serve liquid cold drinks switch the temperature control button(s) to the Water Drops position.
9. The mix should start to slush in approximately 60 minutes. If it does not, the power source is not correct.
10. As a precautionary measure start up the machine full of mix about 2 hours before you want to start serving. If you don't see slushy mix in about 45 minutes then you do not have the machine plugged into a dedicated circuit. Plug the machine into a different outlet and try again!
11. If you plan on making a second batch, mix it up right away, as per the mix instructions in step 5, and keep the mix cold. The colder the mix, the faster it will freeze.
12. Keep adding mix to the machine as the product is used up. Avoid allowing the mix level from running low because adding liquid mix to the machine will increase the temperature of and liquefy the frozen mix already in the bowl.

Frozen Drink Machine Cleaning Instructions

1. Put cold water in the machine and drain it out until ALL the product is out of the machine. **DO NOT LEAVE ANY PRODUCT IN THE MACHINE.**
2. Put warm water in the machine and let the machine run for a minimum of 5 minutes. Drain the water out of the machine and turn the machine off.
3. Wipe the exterior with a damp cloth until clean. Make sure no sticky mix is left on the outside. Clean and return the 5 gallon Mixing Jugs.
4. Make sure that machine and mixing jugs are clean in order to be refunded your cleaning deposit.

