

Popcorn Machine Operating Instructions

1. Plug in the Popcorn Machine. Machine needs to be plugged into a 110-volt dedicated circuit to operate properly.
2. Turn HEAT and LIGHT switch to ON (Wait 3-4 minutes for kettle to heat up). The kettle will get very hot! **USE CAUTION ALWAYS.**
3. When ready to add oil and popcorn, turn KETTLE MOTOR switch ON to start the motor.
4. Open the oil pouch and pour into the kettle.
5. Immediately add the popcorn. (DO NOT OVERFILL: only pop one popcorn pack at a time.)
6. Pull the kettle lid downward from the top of the cabinet to cover the kettle. DO NOT FORGET TO COVER THE KETTLE OR THE OIL AND POPCORN WILL IMMEDIATELY SPRAY OUT ALL OVER THE SIDES OF THE MACHINE.
7. While the corn is popping open the plexiglass doors slightly to prevent fogging.
8. Popcorn will pop quickly, and when the popping ceases, TURN BOTH THE KETTLE HEAT AND MOTOR SWITCH OFF.
9. Dump popped corn by releasing the kettle, pushing the black handle downward.
10. Put the kettle back in place using the black handle to hook the kettle to the holding bolt. **CAUTION: THE KETTLE IS VERY HOT!**
11. Repeat steps 2-10 for additional batches. Each dual pack of popcorn and oil makes 10 2-cup servings.
12. If you are making several batches continuously you do not have to wait for machine to reheat. It will already be pre-heated.
13. Remember to turn HEATING LIGHT SWITCH to ON in order to keep your popcorn warm.

Popcorn Machine Cleaning Instructions

1. Wait at least one hour until the kettle has completely cooled. **CAUTION:** The kettle can be very hot.
2. Wipe all oil off the inside and outside of the kettle with a DRY clean soft cloth. **NEVER PUT WATER ON THE KETTLE!!**
3. Wipe down the Inside & Outside of the machine and the popcorn scoop. Make sure to clean out the small tray located at the bottom of the machine.
4. Popcorn machine must be returned clean in order to be refunded the \$30.00 cleaning deposit for the machine.

